





## Front Panel Configuration (FPC)

Your radio is able to customize certain feature parameters to enhance the use of your radio.





### Entering FPC Mode

- 1  to access the menu.

---




  - 2  or  to Utilities and press  to select.


---

  - 3  or  to Program Radio and press  to select.
- Long press  at any time to return to the Home screen.

### Editing FPC Mode Parameters




Use the following buttons as required while navigating through the feature parameters:

- ,  – Scroll through options, increase/decrease values, or navigate vertically.
-  – Select the option or enter a sub-menu.

-  – Short-press to return to previous menu or to exit the selection screen. Long-press to return to Home screen.

### Checking the RSSI Values

Your radio shows the Received Signal Strength Indicator (RSSI) icon at the top of your display. This feature allows you to view the RSSI values.

On the home screen, press  three times and immediately press , all within 5 seconds. The display shows current RSSI values. Long press the  to return to the Home Screen.

See [Display Icons](#) on page 35 for details on RSSI icon.